Splicing Operation

Turning splicer ON

Confirming splice, heater and operation modes

Cleaning coating or sheath of fiber

Placing protection sleeve over fiber

Stripping fiber

Cleaning fiber

Cleaving fiber

Loading fiber onto splicer

Splicing start automatically

Visual inspection on LCD during splice

Removing spliced fiber

Centering protection sleeve in tube heater

Centering spliced point in tube heater

Heating start automatically

Completed

Note

 When splicing only standard SM fibers (ITU-T G.652), "SM AUTO" mode is recommended.

 When splicing different types of fibers, "AUTO" mode is recommended, but splice speed is slow.

 Splicing speed of "SM FAST" mode is fast, but periodical Arc calibration is required.




Make sure the stripped fiber is free of coating debris or contamination.

 Use only 99% or better purity alcohol.

 Do not allow the cleaved fiber ends to touch anything or become contaminated.

Place the fiber end between
 V-groove edge and Electrode center.




*Hold the fiber at edge of splicer body.

**Apply tension to the fiber until heater cover closes completely.

 When splicer indicates following message, splice loss may be high "Arc discharge is not stable. Electrodes should be stabilized to reform the arc discharge."


. Load prepared SM fibers onto splicer in order to stabilize electrodes. After completeing it, re-splice fibers.

· When an altitude changes drastically, stabilizing elctrodes must be excecuted before splicing.





How to use Keypad



Power Supply



AC Adapter

- Input power: AC100-240V, 50-60Hz
- · Use only supplied AC power cord.
- Connect to ground with ground terminal of AC power cord.
- When using a AC power generator, check output voltage periodically with a circuit tester.

DC operation

- Input power: DC12V
- · Use only supplied DC power cord.

Battery Pack



Rechage by DC is also possible

- ♦ Connect AC adapter (ADC-18) and battery pack (BTR-09) with battery recharge cord (DCC-18).
- Do not stack battery pack on top of AC adapter while recharging.
- ♦ Recharging temperature: 0~40°C (32~104°F)





Confirm power saving function is working when using battery



Cleaning before Splice Operation

V-grooves



- Clean bottom of V-groove with a thin cotton swab moistened with alcohol.
- Remove excess alcohol from V-grooves with a clean dry swab.
- · Use a cleaved fiber end-face to dislodge.

Caution of cleaning

- · Do not contact the electrode tips.
- Use only 99% or better purity of alcohol.

Fiber Clamp Chips



- Fiber Cleaver

 Clean rubber pads.
- Clean rubber anvil.
- · Clean blade.





Objective Lens




When lens is dirty, clean it.

Replace Electrodes

Electrodes

- When "Replace electrodes" message appears, or when the tip is damaged, replace electrodes.
- Execute [Replace Electrodes] in Maintenance Menu.
- Exchange for a new electrode the old electrode currently attached to equipment.
 Use attached screw driver (SD-01).

Remove the electrode cover



Remove the old electrode



Place the electrode cover

Tighten screws

Install new electrode

- · Load prepared fibers onto the splicer.
- Execute [Stabilized Electrodes]
- · [Arc Calibration] is executed.



Ways of Solution of an Error

Error Message	Reason	Solution		
Too Long Fiber	The fiber end-face is placed on the electrode centerline, or beyond it. The cleave length (bare fiber part) is too long Dust or dirt is on the objective lens.	Press RESET, and set the fiber end-face between the electrode centerline and the V-groove edge. Confirm the setting position of the stripped fiber end on the fiber cleaver. Check the cleave length. Execute the [Dust Check]. Clean the lens when dust or dirt exists.		
Too Dusty Fiber	Dust or dirt is on the fiber surface. Dust or dirt is on the objective lens. [Cleaning Arc] time is too short or "OFF." Splicing indistinct core fibers with the SM or DS modes. [Align] is set to "Core" to splice indistinct core fibers when using other splice modes. [Focus] is incorrectly set when using other splice modes. The fiber end-face is placed on the electrode centerline, or beyond it.	Completely prepare the fiber again (strip, clean and cleave). Execute the [Dust Check]. Clean the lens if dust or dirt exists. Set the [Cleaning Arc] time to "150ms." When splicing carbon coated fibers, set to "200ms." Use the MM mode to splice indistinct core fibers (i.e. MM fiber). Set [Align] to "Clad" to splice indistinct core fibers (i.e. MM fiber). Set [Focus] to "Edge" to splice indistinct core fibers (i.e. MM fiber). To splice distinct core fibers, "Auto" or the correct focus value should be entered.		
ZL/ZR Motor Overrun	The fiber is set too far back and does not reach the splice point. The fiber is not set correctly at the bottom of the V-groove. The fiber is not located in the Camera's field of view. The cleave length (bare fiber part) is too short.	Press RESET, re-position the fiber again with the end-face closer to the electrodes. Press RESET, and set the fiber again to seat it correctly at the bottom of the V-groove. Confirm the setting position of the stripped fiber end on the fiber cleaver. Check the cleave length.		
Large Cleave Angle	Bad fiber end-face. [Cleave Limit] is set too low	Check the condition of the fiber cleaver. If the blade is worn, rotate the blade to a new position. Increase the [Cleave Limit] to an adequate limit.		
Cleave Shape NG	Bad fiber end-face.	Check the condition of the fiber cleaver. If the blade is worn, rotate the blade to a new position.		

Contact Address

Euiikuwa I tel	1-5-1 Kiba, Koto-ku, Tokyo 135-8512 Japan		
Fujikura Ltd.	Phone: +81-3-5606-1131	Fax: +81-3-5606-1528	http://www.fujikura.co.jp
Fujikura (CHINA) Co., Ltd.	7 th Floor, Shanghai Hang Seng Bank Tower 1000Lujiazui Ring Road,Pudong New Area ShanghaiZIP200120,China		
Fujikura (CHINA) Co., Ltd.	Phone: +86-21-6841-3636	Fax: +86-21-6841-2070	http://www.fujikura.com.cn
Fujikura Asia Ltd.	438A Alexandra Road, #08-03 Blk A Alexandra Techno Park, SINGAPORE, 119967		
Fujikura Asia Ltu.	Phone: +65-6-2711312	Fax: +65-6-2780965	http://www.fujikura.com.sg
Fujikura Europe Ltd.	C51 Barwell Business Park, Leatherhead Road, Chessington, Surrey KT9 2NY England		
Fujikura Europe Etu.	Phone: +44-20-8240-2000	Fax: +44-20-8240-2010	http://www.fujikura.co.uk
AFL Telecommunications	260 Parkway East, Duncan, SC 29334 USA		
AFE Telecommunications	Phone: +1-800-235-3423	Fax: +1-864-433-5560	http://www.AFLglobal.com

URL: http://www.fusionsplicer.fujikura.com

